



Eco-Pro 3 HRU Controller  
vP3.0 02/2016



J13 - 4  
J13 - 5  
J13 - 6  
J13 - 7  
J13 - 8



DESCRIPTION:  
Eco-Pro 3 controller layout  
MANUAL BOOST CONTROL WIRING

DATE: 09/08/2016

<h1>Eco-Airvent</h1>	
DESCRIPTION MANUAL BOOST CONTROL WIRING DIAGRAM	REV. A
SCALE: NTS	SHEET 1 OF 1

NOTES:  
 \* we reserve the right to make modifications to the current wiring diagram without any prior notice  
 \* local installation and wiring must be made by qualified personnel only (if in doubt, ASK)  
 \* wiring diagram applicable ONLY with Eco-Airvent provided manual boost control faceplate