



NOTES:
 * we reserve the right to make modifications to the current wiring diagram without any prior notice
 * local installation and wiring must be made by qualified personnel only (if in doubt, ASK)
 * wiring diagram applicable ONLY with Eco-Airvent provided manual boost and power control faceplate